


Connect the Wiring

The analog devices connect to the analog module through a field wiring arm (cat. no. **1771-WC**). The field wiring arm pivots on the front of the I/O chassis to connect with the module. You can remove the module from the chassis without disconnecting user wiring because wiring connections are made on the field wiring arm. The connection diagram (Figure 2.5) shows connections to the field wiring arm.



ATTENTION: To avoid injury to personnel and damage to equipment, disconnect and lockout ac power from the processor and system power supplies before wiring the module.

Figure 2.5
Connection of Analog Devices to the Field Wiring Arm (cat. no. 1771-WC)



12878

