Part Number: ATEX218 Publish date: July 2021

KJ2005X1-MQ2 MQ Controller

Hazardous Atmosphere



II 3G Ex ec IIC Gc FM19ATEX0173U IECEx FMG 19.0019U FM21UKEX0017U



CL. I Div. 2 GP. A,B,C,D CL. I Zone 2 AEx/Ex ec IIC Gc FM17CA0145U FM17US0286U

Power Specifications

Local Bus Power +5 VDC at 1.4 A

Environmental Specifications

Ambient -40°C to +70°C

Temperature

Shock 10g ½ Sinewave for 11msec

Vibration 1mm Peak to Peak from 2 to 13.2Hz;

0.7g from 13.2 to 150Hz

Airborne ISA-S71.04 –1985 Airborne Contaminants Class G3

Relative Humidity 5 to 95% Non-Condensing

Note: Refer to the product label for serial number and location and date of manufacture.

Warning: This product has specific instructions for installation, removal and operation in hazardous areas. Refer to document 12P2046 "DeltaV™ Scalable Process System Zone 2 Installation Instructions". Other installation instructions are available in the "DeltaV™ M-Series Hardware Installation and Reference" manual.

The communications network connected to the DeltaV Remote Interface Unit must not be connected to a source that generates or contains under normal conditions a potential in excess of 60 VAC or 75 VDC.

Removal and Insertion

This unit cannot be removed or inserted with system power energized unless the area is known to be non-hazardous.

Maintenance and Adjustment

This unit contains no user serviceable parts and should not be disassembled for any reason. Calibration is not required.

Other Safety Approvals





