

Proper polarity, as indicated in the connection diagram, must be observed with dc power connections. Reverse polarity, or application of a voltage outside the product ratings may cause damage to the module.

You can use an output of the 1771–OC module to drive an input of a DC (48V) input module (1771–IC) to indicate status, such as the turning on a motor starter (Figure 2).



Use the same dc power source to power both modules to ensure that ground is at the same potential.



(Actual wiring runs in this direction.)

8

DC Output Driver Module

(Catalog Number 1771-OC)

To The Installer

This document provides information on:

То	See page
Important User Information	1
Pre-installation Considerations	3
Calculate Power Requirements	4
Determine Module Placement	4
Prevent Electrostatic Discharge	4
Key the Backplane Connector	5
Install the Module and Field Wiring Arm	6
Connect Wiring to the Module	7
For this reference information	See page
Interpreting the Status Indicators	9
Replacing a Fuse	10
Specifications	11

Important User Information

Because of the variety of uses for the products described in this publication, those responsible for the application and use of these products must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards. In no event will Rockwell Automation be responsible or liable for indirect or consequential damage resulting from the use or application of these products.

Any illustrations, charts, sample programs, and layout examples shown in this publication are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Rockwell Automation does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.